



EDELHOLZ™
Original Massiv Parkett

CARE INSTRUCTION

PRINCIPAL collection

REGULAR CLEANING – QUICK AND EASY

To keep your high-quality parquet floor beautiful for many years and to enjoy it for a long time, it must be cleaned and maintained regularly and correctly.

DAILY



The easiest way to clean your wooden floor is with a **soft-bristled broom** or a **vacuum cleaner**.

MONTHLY

Floors in living areas that are normally soiled should be mopped at least once a month using OLI-NATURA Wood Soap. In areas subject to heavy use or high foot traffic, we recommend performing wet cleaning at least once a week.



1. Remove coarse dirt by sweeping or vacuuming.



2. Shake well before use.



3. Simply add about 3 bottlecaps wood soap to 5 liters of warm water (in case of large surfaces, about 6 bottlecaps to 10 liters of warm water).



4. Dip the mop into the soap solution and wipe the surface damp. Let it sit for a few seconds to loosen the dirt, then use a clean mop to remove the dirty water from the floor. After use, always rinse the dirty mop or cloth thoroughly with clean water. (Recommendation: Work with two buckets – one for washing and one for rinsing.)

Note: After cleaning, make sure that no puddles of water remain on the surface. Conventional household cleaners should never be used, as they can dry out the wood and damage the protective finish.

Keep OLI-NATURA Wood Soap out of reach of children!

USEFUL TIPS



Use only cleaning and care products that are suitable for the specific type of flooring and recommended by the manufacturer.



To prevent scratches, attach felt pads to the legs of chairs and other furniture; for items with castors, protect the floor with suitable mats.



Make sure no excessive water remains on the surface.



Do not use steel wool or abrasive pads for cleaning.



For wooden floors, it is important to maintain a relative humidity between 40% and 60%. Houseplants and/or a humidifier can help to achieve this.