




EDELHOLZ™
Original Massiv Parkett

MAINTENANCE & CARE INSTRUCTIONS

ALPENPASS collection

REGULAR CLEANING – QUICK AND EASY

To ensure that your floor stays beautiful for a long time and that you enjoy your floor for many years, it must be maintained and cleaned regularly and above all, properly.



DAILY CLEANING

The simplest way to clean your floor is with a soft-bristle broom or a vacuum cleaner.

MONTHLY CLEANING

We recommend cleaning floors that experience average household use at least once a month with OLI-NATURA Wood Soap. Frequently used and heavily stressed areas should be cleaned at least once a week.



1. Remove coarse dirt by sweeping or vacuuming.



2. Shake well before use the bottle of the OLI-NATURA Wood Soap.



3. Add approx. 3 caps of wood soap to 5 litres of warm water (for larger areas, increase the amount proportionally — e.g. 6 caps for 10 litres of warm water).



4. Dip the mop into the soapy solution, wipe the surface while damp, let the solution loosen the dirt for a few seconds, then wipe away the dirty water with a clean mop. Always rinse dirty mops or cloths thoroughly in clean water after use. (Tip: Use two buckets — one for soapy water and one for rinsing.)

Note: After mopping, ensure that no standing water remains on the surface.

Never use conventional household cleaners, as they can dry out the wood and damage the surface finish of the floor or parquet.

Keep OLI-NATURA Wood Soap out of reach of children!

USEFUL TIPS



For maintenance and care, always use cleaning products specifically recommended by the manufacturer and suitable for your exact floor type.



Attach felt pads to the bottoms of chair legs to prevent scratching the floor. Place protective mats under rolling chairs.



Make sure no standing water remains on the surface!



Do not use wire brushes for cleaning.



Maintaining the correct relative humidity between 40% and 60% is essential for wooden floors. Houseplants and/or humidifiers can help achieve this.